

## RPS TTL Digital Flash Brackets

### RPS TTL Digital Flash Bracket

- Includes **IMPROVED Heavier Duty TTL Cord**
- **NEW! Horizontal and Vertical Locking Lever**
- Flash can be extended up to 18 inches
- Includes Shutter Release and TTL Cord for your camera
- Quick rotate to vertical or horizontal • Locks in position
- Flash stays centered over the lens • Left hand or right hand use
- Includes storage pouch

<b>RS-0420/C3</b>	For Canon 3 Pin (5D, 7D, 10D, 20D 30D, 40D, 50D)
<b>RS-0420/EOS</b>	For Canon Rebel (2.5 Mini plug) Series
<b>RS-0420/D90</b>	For Nikon D90 and D5000
<b>RS-0420/N10</b>	For Nikon 10 Pin (D200, D300, D700, D3 series)
<b>RS-0420/NA</b>	For Nikon Single Pin (D70s, D80)
<b>RS-0420/O</b>	For Olympus DSLR
<b>RS-0420/P</b>	For Pentax (K10D, K100D, K20D, K200D)
<b>RS-0420/S</b>	For Sony "a" Series DSLR



### RPS TTL Digital Flash Bracket with Tilt

- **IMPROVED Heavier Duty TTL Cord**
- **NEW! Horizontal and Vertical Locking Lever**

All of the features of the original RS-0420 Bracket, but now includes a bounce control for the flash. This is especially useful for close up work. Allows you to direct the flash downward. Used in conjunction with the extendable arm, this bracket gives you more control under more situations. Includes Shutter Release and TTL Cord for your camera

<b>RS-0424/C3</b>	For Canon 3 Pin (5D, 7D, 10D, 20D 30D, 40D, 50D)
<b>RS-0424/EOS</b>	For Canon Rebel (2.5 Mini plug) Series
<b>RS-0424/D90</b>	For Nikon D90, D5000
<b>RS-0424/N10</b>	For Nikon 10 Pin (D200, D300, D700, D3 series)
<b>RS-0424/NA</b>	For Nikon Single Pin (D70s, D80)
<b>RS-0424/O</b>	For Olympus DSLR
<b>RS-0424/P</b>	For Pentax (K10D, K100D, K20D, K200D)
<b>RS-0424/S</b>	For Sony "a" Series DSLR

## The STEALTH Bracket

*So Comfortable you'll hardly know it's there!*

- Includes **IMPROVED TTL Cord**
- **Regular or Extended height**
- **Flips to vertical**

<b>RS-0410C</b> For Canon	<b>RS-0412C</b> Ext Ht for Canon
<b>RS-0410N</b> For Nikon	<b>RS-0412N</b> Ext Ht for Nikon
<b>RS-0410P</b> For Pentax	<b>RS-0412P</b> Ext Ht for Pentax
<b>RS-0410S</b> For Sony	<b>RS-0412S</b> Ext Ht for Sony

